

# New Fixture Flushing Tracking Sheet

New fixtures must be thoroughly flushed prior to resampling. When first installed, new fixtures may release greater amounts of lead and other contaminants into the water. Following the flushing procedure described below conditions the fixture and is necessary to avoid artificially high results. This process is required prior to resampling according to the Written Directives [PIN 21-21-CCP](#), section 101705(b)(2).

**Flushing Directions:** Post a copy of this sheet near each newly replaced fixture. Fill in the Facility License Number, Fixture ID, and the date the fixture was installed. Run the fixture 4 times per day for at least 30 seconds, for at least 3 weeks (weekdays only). You must continue flushing daily past the 3-week mark until the fixture is prepared for sampling 8-18 hours before the sampler arrives. Log all flushes on the table below. A completed tracking sheet must be available to the sampler upon arrival and kept on file by the Child Care Center.

Contact CRWA at (855) 916-4798 or [ab2370leadsampling@calruralwater.org](mailto:ab2370leadsampling@calruralwater.org) with any questions.

Facility License #	Fixture ID:	Date Installed:
--------------------	-------------	-----------------

	Date	30-second Flush 1		30-second Flush 2		30-second Flush 3		30-second Flush 4	
		Time	Initials	Time	Initials	Time	Initials	Time	Initials
Week 1									
Week 2									
Week 3									

Additional space is available on the back of the tracking sheet for continued flushing.

## New Fixture Flushing Tracking Sheet

	Date	30-second Flush 1		30-second Flush 2		30-second Flush 3		30-second Flush 4	
		Time	Initials	Time	Initials	Time	Initials	Time	Initials
Week 4									
Week 5									
Week 6									
Week 7									
Week 8									